

# 20MM BALL ADAPTER CHARGING INSTRUCTIONS



more info

[pkdsn.com/chargingballadapter](https://pkdsn.com/chargingballadapter)

## GET TO KNOW YOUR MOUNT

requires Peak Design Case or MagSafe Phone/Case not included



Embedded Magnets x4

USB-C



Cable Clips x3



Charging Port



USB-C to USB-C Cable (1m)

## INSTALLATION



Connect Peak Design 20mm Ball Adapter to 3rd party 1" ball and socket mount. Tighten to 3rd-party specifications.

Allow alcohol to dry when using included wipe to clean surfaces for Cable Clips.



**Stay safe.** Do not interact with or remove your phone from the mount while in motion.

## ATTACH/DETACH PHONE



The Mount Head magnetically connects to the back of your phone. Once connected, confirm phone is charging via phone screen.

**WARNING:** If not attached correctly, product and/or phone may dislodge or be thrown into air in event of crash. Consult your car's manual to ensure mount does not cover or interfere with operation of airbag.