

DJI OSMO ACTION 系列运动相机配件通用列表

配件名称	Osmo Action 4	Osmo Action 3	DJI Action 2	Osmo Action 灵眸运动相机
Osmo Action 迷你延长杆	√	√	×	×
Osmo Action 1.5 米延长杆套件	√	√	×	×
Osmo Action 360° 腕带	√	√	×	×
Osmo Action 曲面粘接底座	√	√	√	√
Osmo Action 曲面粘接底座套件	√	√	√	√
Osmo Action 粘接底座套件	√	√	√	√
Osmo Action 快拆转接件	√	√	×	×
Osmo Action 全能安装套装	√	√	√	√
Osmo 磁吸球头组件	√	√	√	×
Osmo 锁紧螺杆	√	√	√	√
Osmo 肩带支架	√	√	√	√
Osmo Action 挂脖支架	√	√	√	√
Osmo Action 迷你车把夹	√	√	×	×
Osmo Action 车把夹	√	√	√	√
Osmo Action 车载吸盘	√	√	√	√
Osmo Action 骑行胸带	√	√	√	√
Osmo Action 头盔下巴配件	√	√	√	√
Osmo Action 骑行配件套件	√	√	√	√
Osmo Action 公路车配件套件	√	√	×	×
Osmo Action 车座支架	√	√	√	√
Osmo Action 冲浪保险贴	√	√	√	√
Osmo Action 冲浪保险贴套件	√	√	×	×
Osmo Action 60 米防水壳	√	√	×	×
Osmo Action 潜水配件套件	√	√	×	×
DJI 漂浮手把	√	√	√	√
Osmo Action ND 镜套装	√	√	×	×
Osmo Action 4 玻璃镜头保护盖	√	×	×	×
Osmo Action 横竖拍保护框	√	√	×	×
Osmo Action GPS 蓝牙遥控器	√	×	×	×
Osmo Action 耐寒长续航电池	√	√	×	×
Osmo Action 多功能电池收纳盒	√	√	×	×
Type-C to Type-C PD 快充线	√	√	√	√
DJI 30W USB-C 充电器	√	√	√	√
DJI Action 2 磁吸保护框	×	×	√	×
DJI Action 2 蓝牙遥控延长杆	×	×	√	×
DJI Action 2 防水壳	×	×	√	×
DJI Action 2 微距镜	×	×	√	×
DJI Action 2 磁吸头带	×	×	√	×
DJI Action 2 磁吸球头组件	√	√	√	×